



In-Core Irradiation Capabilities at the Neutron Radiography Reactor

February 2021

Changing the World's Energy Future

Andrew T Smolinski



DISCLAIMER

This information was prepared as an account of work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness, of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. References herein to any specific commercial product, process, or service by trade name, trade mark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the U.S. Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the U.S. Government or any agency thereof.

In-Core Irradiation Capabilities at the Neutron Radiography Reactor

Andrew T Smolinski


February 2021

**Idaho National Laboratory
Idaho Falls, Idaho 83415**

<http://www.inl.gov>

**Prepared for the
U.S. Department of Energy
Under DOE Idaho Operations Office
Contract DE-AC07-05ID14517**

In-Core Irradiation Capabilities at the Neutron Radiography Reactor (NRAD)




Andrew Smolinski
NRAD Nuclear Reactor Systems Engineer
Idaho National Laboratory

NRAD Reactor Attributes

- 250kW TRIGA® Reactor (Conversion Type)
- Cooling System:
 - Shallow Open Pool (Atmospheric Pressure)
 - Radiation levels (~2.5R/hr) prevent pool-top access during full power operation.
 - Access is permitted <1kW with RWP controls.
 - Demineralized water
 - Purification system filters and removes contaminants through mixed resin beds
 - Natural circulation through the core
 - Primary Cooling System removes excess heat from tank
 - Tank Temperatures 20-40°C (Typically ~37°C steady state)
- Reactor Fluxes (Gold Foil):
 - In-Core Position C4SW (Wet-tube) 5.2×10^{12} n/cm²-s
 - In-Core Position F-1 (Dry-Tube) 2.1×10^{12} n/cm²-s
 - East Radiography Station (ERS) 9.5×10^6 n/cm²-s
 - North Radiography Station (NRS) 4.5×10^6 n/cm²-s
- Direct Access to HFEF hot cell permits experiment transfer <24 Hours from end of irradiation


NRAD Position Within HFEF




Cask Tunnel, NRAD Cask, and Decon Cell Penetrations allow for experiment transfer to hot cell in <24 hrs.

Reactor Positioned Beneath HFEF Hot Cell


NRAD Beam Systems



NRAD Core Layout



- Approved 64-element core configuration
 - 64 TRIGA® LEU SS-clad Elements
 - 4 Graphite reflector elements
 - 12 Graphite block reflectors
 - 2 beam lines
 - 2 empty grid positions (F-1, A-6)
 - 1 empty fuel element location with guide tube (C4SW)
 - 3 Control rods
- SAR change in progress to allow for core re-configuration to accommodate larger experiments
- 8 in-pool storage locations (G-M)




- Control rod
- Neutron source (AmBe)
- Irradiation positions
- Graphite reflector element
- Fission Chamber (FC)
- Compensated Ion Chamber (CIC)

NLW - Wide Range Log Channel
NMP - Multirange Linear Channel


NRAD Axial Flux Shape

- ~10cm flat flux near core centerline in dry tube
- ~7 cm flat flux at core centerline in C4SW
- *NOTE: Fluxes noted in the chart are measured at 250W. Scale up 3 decades for full power fluxes.*



NRAD Reactor

C4SW and associated wet tube is used for higher flux irradiations that require cooling.





Dry Tube can be positioned in empty core position F-1 for experiments that must stay dry.

Routine Dry Tube Experiments

Example containers

Polycarbonate container



Dry Tube positioned in empty core position F-1. Experiment suspended from titanium wire at core centerline.

Contact handling RWP limit - <math><25\text{R/hr}</math> on contact.




C4SW Wet Tube Experiments

Lower Dose Sample Transfer to DAW Cask. Water bucket used for additional shielding – AGR particle re-irradiation campaign



C4SW Sample Irradiation – In-tank camera





Example containers
Titanium and Aluminum Available



NRAD Cask on tank bottom. Plug removed for sample transfer.


NRAD Cask Transfer for High Dose Samples – AGR full compact re-irradiation campaign

MCNP model of capsule in C4SW on Al sample stand. Stand ensures capsule stays at core centerline.



NRAD Cask

- Shielding Capability:
 - 8" lead on walls
 - 6" lead top, 4" lead bottom
- 7000 lbs
- Top-Loading
- Qualified for use in HFEF/NRAD cask tunnel for transfers only.
- Internal Dimensions
 - 4.5" ID
 - 39" internal height
- Contents controlled by LST-394 Crit Safety List
 - ≤ 4 TRIGA[®] Elements, OR
 - 150g MFE



NRAD Experiment Process

(NRAD-NOP-5003 NRAD Experimenter's Guide)

Experiment Proposed

Out-of-Tank

In-Tank

Not Previously Approved

Previously Approved:
Bounded by Previous ESA

Material Acceptance and Transfer
Paperwork Development:

Experimenter/NRAD System
Engineer/Radiographer Provides
Prescription:

- Facility location
- Power level
- Irradiation time
- Shaper/scraper settings
- Decay time prior to handling
- Shielding – post irradiation
- Decay time prior to release

Material Positioning and Irradiation

Experiment Retrieval and Transfer

General Information:

- ESAs can bound several samples
- ECARs should be used for ESAs for In-core experiments.
- Anything that is intended to be released back to the public needs a Form 441.47 initiated and Radcon involvement up front.

Rx Manager Scope Approval

Experimenter/NRAD System
Engineer Provides
Prescription:

- In-tank location
- Power level
- Irradiation time
- In-tank decay time
- Shielding – post irradiation

Rx Manager Prescription Approval

Material Acceptance and Transfer
Paperwork Development

Experiment Acceptance and
Positioning

Reactivity Worth Determination and
Material Irradiation

ESA ECAR Approval:

- Reactivity Tech Checker
- System Engineer
- Industrial Safety
- Nuclear Safety
- Criticality Safety
- Radcon
- Nuclear Facility Manager

USQ the
Experiment
Bounds

Rx Manager
Scope Approval

Experimental Safety Analysis (ESA) -

(SAR-406 SARC 8.406.2)

- Description
 - Size
 - Composition
 - Mass
 - Form
 - MFE
 - Encapsulation
 - SECURED/UNSECURED
- Core Physics
 - Estimated reactivity worth
 - Effects on control rod worth
 - Effects on core shutdown margin
- SSC Impacts
 - Control rod insertion interference
 - NI efficiency or shadowing
 - Reactor shielding
- Fuel Impacts
 - In-tank location (proximity to fuel)
 - Effects on cooling flow
 - Chemical interaction
- ALARA
 - Dose consequence (MAR)
 - Pre-and Post-irradiation rad levels
 - In-tank decay time
 - Shielding – post irradiation
 - Potential failure modes (Tank water contamination)

NRAD In-Core Experiment Costs

(Estimates – Subject to change)

Single Shift (10 hrs) Irradiation with sample insertion, retrieval, and transfer

#	Activity Title	Labor Hours	FTE	Loaded Labor	Non-Labor	Total
1	NRAD Reactor Ops (10 hr shift)	20.00	0.01	\$3,200.30	\$0.00	3,200.30
2	Sample Insertion (one sample)	7.00	0.00	\$1,059.97	\$0.00	1,059.97
3	Sample Retrieval (One Sample)	6.00	0.00	\$856.08	\$0.00	856.08
4	Sample Transfer	14.00	0.01	\$2,200.75	\$0.00	2,200.75
		47.00	0.03	\$7,317.10	\$0.00	\$7,317.10

#	Activity Title	Labor Hours	FTE	Loaded Labor	Non-Labor	Total
1	NRAD Reactor Ops (24-hr Coverage)	52.00	0.03	\$8,598.69	\$0.00	8,598.69
2	Sample Insertion (One Sample)	7.00	0.00	\$1,059.97	\$0.00	1,059.97
3	Sample Retrieval	6.00	0.00	\$856.08	\$0.00	856.08
4	Sample Transfer	14.00	0.01	\$2,200.75	\$0.00	2,200.75
		79.00	0.04	\$12,715.50	\$0.00	\$12,715.50


#	Activity Title	Labor Hours	FTE	Loaded Labor	Non-Labor	Total
1	ESA Development, Review, and Approval	270.00	0.15	\$47,574.98	\$0.00	47,574.98
		270.00	0.15	\$47,574.98	\$0.00	\$47,574.98

7-day Continuous Irradiation with NRAD Cask Transfer for insertion and removal, and Decon cell ops


#	P6 Act-ID	Activity Title	Labor Hours	FTE	Loaded Labor	Non-Labor	Total
1		Reactor Operations	336.00	0.19	\$63,180.63	\$0.00	63,180.63
2		Pre-Irradiation Cask Handling System Rails Install	16.00	0.01	\$2,355.53	\$0.00	2,355.53
3		Post-Irradiation Cask Handling System Rails Install	16.00	0.01	\$2,355.53	\$0.00	2,355.53
4		Pre-Irradiation Cask Handling System Rails Removal	12.00	0.01	\$1,694.14	\$0.00	1,694.14
5		Post-Irradiation Cask Handling System Rails Removal	12.00	0.01	\$1,694.14	\$0.00	1,694.14
6		Post-Irradiation NRAD Cask Bag In/Out to Decon Cell	40.00	0.02	\$6,211.38	\$0.00	6,211.38
7		Pre-irradiation NRAD Cask Bag In/Out to Decon Cell	40.00	0.02	\$6,211.38	\$0.00	6,211.38
8		Cask Transfer to NRAD Before Irradiation	44.00	0.02	\$6,486.52	\$0.00	6,486.52
9		Cask Transfer From NRAD After Irradiation	44.00	0.02	\$6,486.52	\$0.00	6,486.52
10		Decon Cell Sample Load	10.00	0.01	\$1,655.39	\$0.00	1,655.39
11		Decon Cell Sample Unload	10.00	0.01	\$1,655.39	\$0.00	1,655.39
12		Interfacility Transfer Paperwork	17.00	0.01	\$2,839.41	\$0.00	2,839.41
			597.00	0.34	\$102,825.96	\$0.00	\$102,825.96

Advanced Concepts (Options being explored or in the design phase already)





CHARIN Dry-well In-Core Heater (Capable of 900 C)



Multi-Sample Rotating Irradiators



Multi-Sample Hanger



Additional Questions/Clarifications?

- Always contact the facility first to see what's possible. We're flexible.
- Contact:

Andrew Smolinski
NRAD Reactor Systems Engineer
W:(208)533-7579
C:(208)932-6813
Andrew.Smolinski@inl.gov